

WI-PCMS310GF(V2) | WI-PCMS328GF(V2)


1. Packing Content



Switch x 1




Quick Installation Guide x 1



Serial Line x 1



Power Cord x 1




Mounting Accessories (hook x 2, mats x 4, screw x 8)


2. Appearance Overview

WI-PCMS310GF

• Front panel



• Back panel




• LED indicator and button

LED indicators & button	Description
SYS	Blinking: The Device system is operating normally Off: Device system or power connection abnormality
PWR	On: The device power on is normal Off: The device is power off or failed
PoE	On: Equipment connected, normal power supply Off: Port not for terminal equipment power supply
Link	On: Port connected Blinking: Data transmission Off: Port disconnected
Reset	Hold for >5 sec. to restore factory default

WI-PCMS328GF

• Front panel



• Back panel




• LED indicator and button



LED indicators & button	Description
SYS	Blinking: The Device system is operating normally Off: Device system or power connection abnormality
PWR	On: The device power on is normal Off: The device is power off or failed
PoE	On: Equipment connected, normal power supply Off: Port not for terminal equipment power supply
Link	On: Port connected Blinking: Data transmission Off: Port disconnected
Reset	Hold for >5 sec. to restore factory default

3. Installation

• Desktop Installation




• Rack-Mount Installation



4. Configuration

• Desktop Installation

First, the device is powered on, the Internet is connected to the WAN port of the Gateway, the other one LAN port of the Gateway is connected to the PoE Switch, then the PC is connected to the Switch. Ensure that the PC and the Gateway are in the same subnet.



Connection Diagram:



Connection Diagram:



Connection Diagram:



Connection Diagram:



Connection Diagram:



Connection Diagram:



Connection Diagram:



4. Configuration


• Log in to the switch locally

Let the Switch obtain an IP address and then check the DHCP server to see which IP address was assigned.

The Switch is set to DHCP by default, so it will try to obtain an IP address automatically. If that fails, then it will use the default fallback IP address, 192.168.0.1

To log in, follow these steps:

1. Launch your web browser, you type the appropriate IP address in the address bar
2. The login screen will appear. The default username and password are both admin



Note: If the switch device is not connected to the cloud platform, the management account password is admin by default. If it is connected to the cloud platform for management, please go to the cloud platform to check the password. The account is admin, and the password is the WEB password you set when creating the project.



Note: If the switch device is not connected to the cloud platform, the management account password is admin by default. If it is connected to the cloud platform for management, please go to the cloud platform to check the password. The account is admin, and the password is the WEB password you set when creating the project.



Note: If the switch device is not connected to the cloud platform, the management account password is admin by default. If it is connected to the cloud platform for management, please go to the cloud platform to check the password. The account is admin, and the password is the WEB password you set when creating the project.



Note: If the switch device is not connected to the cloud platform, the management account password is admin by default. If it is connected to the cloud platform for management, please go to the cloud platform to check the password. The account is admin, and the password is the WEB password you set when creating the project.




Note: If the switch device is not connected to the cloud platform, the management account password is admin by default. If it is connected to the cloud platform for management, please go to the cloud platform to check the password. The account is admin, and the password is the WEB password you set when creating the project.



Note: If the switch device is not connected to the cloud platform, the management account password is admin by default. If it is connected to the cloud platform for management, please go to the cloud platform to check the password. The account is admin, and the password is the WEB password you set when creating the project.




Note: If the switch device is not connected to the cloud platform, the management account password is admin by default. If it is connected to the cloud platform for management, please go to the cloud platform to check the password. The account is admin, and the password is the WEB password you set when creating the project.




4. Configuration

• Use Telnet to log in to the CLI mode of the switch


Connection Diagram:




Connection Diagram:




Connection Diagram:



Connection Diagram:



Connection Diagram:



Connection Diagram:



Connection Diagram:



Connection Diagram:



Connection Diagram:







4. Configuration

• Cloud login switch configuration

1. Log in to the cloud management interface

(No account, you need to register an account to log in, The URL is: <http://cloud2.wireless-tek.com>)








4. Configuration

• Cloud login switch configuration

1. Log in to the cloud management interface

(No account, you need to register an account to log in, The URL is: <http://cloud2.wireless-tek.com>)






4. Configuration

• Cloud login switch configuration

1. Log in to the cloud management interface

(No account, you need to register an account to log in, The URL is: <http://cloud2.wireless-tek.com>)









4. Configuration

• Cloud login switch configuration

1. Log in to the cloud management interface

(No account, you need to register an account to log in, The URL is: <http://cloud2.wireless-tek.com>)




4. Configuration

• Cloud login switch configuration

1. Log in to the cloud management interface

(No account, you need to register an account to log in, The URL is: <http://cloud2.wireless-tek.com>)






4. Configuration

• Cloud login switch configuration

1. Log in to the cloud management interface

(No account, you need to register an account to log in, The URL is: <http://cloud2.wireless-tek.com>)









4. Configuration

• Cloud login switch configuration

1. Log in to the cloud management interface

(No account, you need to register an account to log in, The URL is: <http://cloud2.wireless-tek.com>)









4. Configuration

• Cloud login switch configuration

1. Log in to the cloud management interface

(No account, you need to register an account to log in, The URL is: <http://cloud2.wireless-tek.com>)



4. Configuration

• Cloud login switch configuration

1. Log in to the cloud management interface