


Quick Installation Guide

Cloud Switch



WI-CGS5018 | WI-CGS5026

1. Package Contents

Cloud Switch * 1

Quick Installation Guide x 1

Power Cord x 1

Serial line x 1

Mounting Accessories (hookx2; MATSx4; screw x 8)

2. Appearance Overview

For WI-CGS5026

- Front panel
 - LED indicator
 - Reset Button
 - 16*1000Mbps SFP Slots
 - 8*10/100/1000Mbps RJ45 Ports
 - Console
 - 2*1000Mbps SFP Slots
- Back panel
 - Power socket
 - Grounding
- LED indicator light

LED	Color	Description
PWR	Green	Off: switch does not power on Permanent: the switch is powered on
System	Green	Blinking: the system works Out: the system is starting or has no power
LNK/ACT	Green	Off: not connected to the network equipment On: connected to 10/100/1000Mbps devices Blinking: connected devices are data transmission

For WI-CGS5018

- Front panel
 - LED indicator
 - Reset switch
 - 8*1000Mbps SFP Slots
 - 8*10/100/1000Mbps RJ45 Ports
 - Console
 - 2*1000Mbps SFP Slots
- Back panel
 - Power socket
 - Grounding
- LED indicator light

LED	Color	Description
PWR	Green	Off: switch does not power on Permanent: the switch is powered on
System	Green	Blinking: the system works Out: the system is starting or has no power
LNK/ACT	Green	Off: not connected to the network equipment On: connected to 10/100/1000Mbps devices Blinking: connected devices are data transmission

3. Installation

- Desktop installation
- Rack Installation

4. Configuration

First, the device is powered on, the Internet is connected to the WAN port of the Gateway, the other LAN port of the Gateway is connected to the PoE Switch, then the PC is connected to the Switch. Ensure that the PC and the Gateway are in the same subnet.

Local Login

- Log in to the switch locally
 - Let the Switch obtain an IP address and then check the DHCP server to see which IP address was assigned. The Switch is set to DHCP by default, so it will try to automatically obtain an IP address. If that fails, then it will use the default fallback IP address, 192.168.0.1
 - To log in, follow these steps:
 - Launch your web browser. Type the appropriate IP address in the address field.
 - The login screen will appear. Enter admin in the Username and Password fields. Login in

Cloud Login

- Log in to the cloud management interface
 - (No account, you need to register an account to log in, The URL is: <http://cloud2.wireless-tek.com>)
 - 2. Enter the cloud binding switch
 - (explain: The switch must be connected to the Internet to bind successfully)
 - Please enter the device serial number to bind a device to the current group, device can be off when binding.
 - Explanation: The 17-digit SN code of the switch is shown on the sticker on the back of the switch as shown in the figure below

Cloud Binding

- After binding, you can use the Switch in the Tunnel option in the cloud management, and then choose to use EWEBoR TELNET to enter the switch. The default account is admin and the password is admin. (After entering the switch, you can configure it based on your own needs)

Warranty Card

Username	
Address	
Telephone No.	
Purchase Shop	
Purchase Address	
Product Model No.	
Purchase Time	
Serial No.	
Dealer Signature	

- If the product defects within three months after purchase, we will provide you a new product of the same model.
- If the product defects within the three-year warranty period, we will provide the professional maintenance service.
- Proof of purchase and a complete product serial number are required to receive any services guaranteed as part of the limited warranty.
- Any other defects that are not caused by workmanship or product quality, such as natural disaster, water damage, extreme thermal or environmental conditions, sticker damaged, warranty card losing will disqualify the product from limited warranty.

Technical Support

Cloud Management

Company Website

Wireless-Tek Technology Limited
 Address: Biaofang Technology Building 402, Bao'an street, Baoan District, Shenzhen City, Guangdong, China
 Website: www.wireless-tek.com
 Tel: 86-0755-32811290
 Email: sales@wireless-tek.com
 Technical Support: tech@wireless-tek.com